Glossary

- Permanent (or stationary) flow: Refers to a flow whose properties do not vary with time.
- Transient flow: Refers to a flow whose properties vary with time.

Abbreviations

- EDF : Electricity of France
- SI: Suitability Index (variable mesh scale)
- HSI: Habitat Suitability Index (mesh scale)
- OSI : Overall Suitability Index (reach scale)
- WUA : Weighted Usable Area (reach scale)
- WUV : Weighted Usable Volume (reach scale)
- UA : Unknown Area in percentage (reach scale)
- AFB: The French Biodiversity Agency
- OFB: French Office for Biodiversity
- GIS: Geographic Information System

From:
https://habby.wiki.inrae.fr/ - **HABBY**

Permanent link:
https://habby.wiki.inrae.fr/doku.php?id=en:lexique_abreviation

Last update: **2022/09/09 14:44**